USG CASTING PLASTER - 20 MINUTE

SOUTHARD, OK

% Expansion

DESCRIPTION

USG Casting Plaster - 20 Minute is a fast-setting high purity general purpose plaster that can be used in a wide variety of applications including architectural ornamentation and dental use. The physical properties can be varied depending upon the desired end use, while the use consistency can vary from a practical range of 63 lbs. water/100 lbs. of plaster (29 kg water/45 kg plaster) to as high as 73 lbs. water/100 lbs. of plaster (33 kg water/45 kg plaster).

When properly used, USG Casting Plaster - 20 Minute sets in 20 minutes and is easy to work with. Always follow handling and use directions and safety warnings on the package. Please contact your local USG Sales Representative for further assistance for specific use information.

Normal Consistency 63 - 73 lbs. water/100 lbs. product (29 - 33 kg water/45 kg product) Hand Mix Vicat Set, Target 14 - 24 minutes % Passing - 50 mesh screen 99 - 100 % Passing - 100 mesh screen 98.5 - 100 Compressive Strength, One Hour After Set 850 - 1250 psi (5.9 - 8.6 MPa) Compressive Strength, Dry 1700 - 2500 psi (11.7 - 17.2 MPa)

 $\textbf{NOTE:} \ \ \text{The Typical Physical Properties} \ \ \text{in the above table were achieved under controlled laboratory conditions with freshly produced material, results may vary.}$

0.15% - 0.20%

MIXING INSTRUCTIONS

TYPICAL PHYSICAL PROPERTIES

MIX PREPARATION

Use potable water at temperatures between 70 °F (21 °C) and 100 °F (38 °C). Because variations in slurry (USG Casting Plaster - 20 Minute and water mixture) temperature produce variations in set time, it is important to keep both the USG Casting Plaster - 20 Minute and water in a stable temperature environment prior to use. The higher the temperature of the slurry, the shorter the set time. Conversely, the lower the temperature of the slurry, the longer the set time.

Weigh both the USG Casting Plaster - 20 Minute and the water prior to use for each mix. The water-to-USG Casting Plaster - 20 Minute ratio is critical because it governs the strength and the density of the final cast.

SOAKING

Sift or strew USG Casting Plaster - 20 Minute into the water slowly and evenly. Do not drop large amounts of USG Casting Plaster - 20 Minute directly into the water as proper soaking of the USG Casting Plaster - 20 Minute may not occur. USG Casting Plaster - 20 Minute should be fully dispersed in the water prior to mixing. Small batches require less soaking time than large batches. See USG IG503 *Plaster Mixing Procedures* for specific soaking instructions.

MIXING

Mixing USG Casting Plaster - 20 Minute slurry is one of the most important steps in producing USG Casting Plaster - 20 Minute casts with optimal strength, absorption, hardness and other important properties.

Mechanically mixed slurries develop uniform casts with optimal strengths. USG Casting Plaster - 20 Minute can be mechanically mixed through both batch and continuous processes. Proper blade and bucket dimensions are important for obtaining the best batch mix (see USG IG503 *Plaster Mixing Procedures* for details).

Longer mixing times result in higher mold strength and shorter set times.



POURING

To prevent air entrainment and provide a uniform, smooth surface, careful pouring of USG Casting Plaster - 20 Minute slurry is necessary. Agitation/vibration of the filled mold is a further step used to prevent air at or near the mold surface. Whenever possible, USG Casting Plaster - 20 Minute slurry should be poured carefully in the deepest area so that the slurry flows evenly across the surface of the case mold.

Pouring a large amount of slurry directly on the face of the case mold may result in slight densification of the USG Casting Plaster - 20 Minute mold at the point where it strikes the surface of the case. This produces a hard spot, giving uneven absorption.

DRYING

All casts should be dried as quickly as is safely possible after manufacture so that maximum physical properties can develop. Dry to a constant weight.

The best drying rooms or ovens provide 1) uniform and rapid circulation (minimum of 15-30 fps (4.6-9.1 mps)) of air with no "dead spots" having little or no air movement, 2) equal temperatures throughout the entire area, and 3) provisions for exhausting a portion of the air while replacing it with fresh air. High humidity surrounding the drying room or oven inhibits drying efficiency because the air pulled into the room is incapable of picking up much moisture from the molds.

The maximum temperature at which USG Casting Plaster - 20 Minute molds are safe from calcination is 120 °F (49 °C). With substantial free water in the mold, a higher drying temperature can be used without difficulty. As drying progresses, the temperature must be reduced to prevent calcination. Before removing molds from the dryer, the temperature should approach that of the area around the dryer to prevent thermal shock. See IG502 Drying Plaster Casts for additional information

STORAGE AND USE

When properly used, USG Casting Plaster - 20 Minute is easy to work with and complies with the federal Labeling of Hazardous Art Materials Act, 12 U.S.C. Section 1277 and ASTM D4236. Keep indoors at temperatures between 65 °F - 75 °F (18 °C - 24 °C) and 45% - 55% RH. Do not stack more than two pallets high. Keep from drafts. Rotate stock. USG Casting Plaster - 20 Minute should be used within six months of the manufacturing date located on the package. Always follow handling and use directions and safety warnings on the package.

PRODUCT INFORMATION

See usg.com for the most up-to-date product information.

CAUTION

When mixed with water, this material hardens and becomes very hot sometimes quickly. DO NOT attempt to make a cast enclosing any part of the body using this material. Dust from mixing may cause irritation to eyes, skin, nose, throat and upper respiratory tract. Use only in a well-ventilated area, wear a NIOSH/MSHA-approved respirator. Wear eye protection. If eye contact occurs, flush thoroughly with water for 15 minutes. If on skin; Wash with plenty of water, If swallowed and/or irritation persists, call physician. For more information call Product Safety: 800-507-8899 or see the SDS at usg.com
KEEP OUT OF REACH OF CHILDREN.

TRADEMARKS

The trademarks USG, IT'S YOUR WORLD. BUILD IT., the USG logo, the design elements and colors and related marks are trademarks of USG Corporation or its affiliates

The information in this document is subject to change without notice. USG Corp. and/or its affiliates assume no responsibility for any errors that may inadvertently appear in this document. Consult your USG sales office or representative for information.

We shall not be liable for consequential, incidental or special damages, directly or indirectly sustained, nor for any loss caused by application of these goods not in accordance with current printed instructions or for other than the intended use. Our liability is expressly limited to the replacement o defective goods or a refund of the purchase price, at USG's option, and does not include costs of labor or any other costs associated with material replacement. Any claim shall be deemed waived unless made in writing to us within thirty (30) days from date it was or reasonably should have been

SAFETY FIRST!

Follow good safety/industrial hygiene practices during installation. Wear appropriate personal protective equipment, Read applicable SDSs and literature before specification and installation.

800 USG.4YOU 800 (874.4968) usa.com

Manufactured by United States Gynsum Company 550 West Adams Street Chicago, IL 60661



